



DE

GB

FR



### The Grinder Art.-No. 5050

Grinds nuts, chocolate or coffee beans and turns sugar cubes into the finest icing sugar when you need it. Max. capacity: 250 ml.

You could call the grinder a small mill, although it has a hammer mechanism rather than a grinder. The ESGE-Zauberstab® which attaches to the grinder is ideal for finely grinding small quantities of fresh or dried herbs, spices, poppy seed, chocolate, nuts, oil seeds or grains (apart from maize). You can use the grinder to make sugar into icing sugar and bread into breadcrumbs.

Fill the foodstuff to be ground into the grinder base. Put the Zauberstab® (without accessories) on the shaft of the grinder. Take the handle of the grinder in the hand. Switch the Zauberstab® on the highest position and shake the grinder slightly with your hand while the knife is rotating, to ensure a good distribution of the food to be grinded. When grinding poppy seed, add 1–2 sugar cubes. Chocolate should be hard when being grinded or chopped.

**Please note:** Ingredients such as clove, cinnamon, cumin, mustard seeds or turmeric contain essential oils. They can discolour the material of the chopper. However, this does not interfere with the function of the appliance. You can wipe off discolouration caused by carrots, herbs or spices with a paper towel and some cooking oil. Wash by hand afterwards. The chopper may become scratched if used for processing such coarse ingredients as rock sugar, hard kinds of salt (e.g. Himalayan salt), etc.

You can remove off-tastes by crushing a slice of toast. This allows you to both remove the taste and reuse the toast crumbs for other dishes.

**Only put into operation with the lid closed! Always store the knife inside the chopper, never separately – risk of injury! The short operating time is 3 minutes. Do not clean in the dishwasher!**



**IMPORTANT NOTE: The ESGE-Zauberette®, the grinder and the processor are not compatible with P 350 Profi and G 350 Gastro Max!**



DE

GB

FR



### Processor with powder disc Art.-No. 5080

For chopping or grinding nuts, spices, chocolate, herbs etc. With powder disc for small quantities and for very fine milling. Max. capacity: 200 ml.

The Processor turns every bowl of muesli into an experience. Freshly ground and garnished with nuts, it brings energy into your everyday life. Likewise, freshly ground filter coffee with its powerful aroma also provides an energy boost. The Processor is an absolute must when it comes to herbs and spices. It transforms fresh ingredients such as basil, wild garlic or mixed herbs into a delicious pesto. Dips and sauces can also be enriched with fresh herbs. Chopped nuts, grains or seeds are a perfect, healthy and beneficial garnish for superfood salads. The flavour of spices such as freshly ground cinnamon, nutmeg or chilli is enhanced and every dish is given a taste of the Far East. The Processor also chops chocolate and nuts for imaginative cakes or decoration. Sugar cubes are quickly and powerfully transformed into icing sugar. Ideal for all dry foods including dried vegetables, hard cheese, dry bread can be turned into breadcrumbs, dried fish and mushrooms, all types of nuts, grains and seeds, and peanuts can be transformed into peanut butter, for example. The Processor is quick and easy to clean, takes up minimal space and can even be stored in holders or on stands to save room – always ready for the next quick and efficient use. The perfect addition to the ESGE-Zauberstab®. Ingredients such as clove, cinnamon, cumin, mustard seeds or turmeric contain essential oils. They can discolour the material of the processor. However, this does not interfere with the function of the appliance. You can wipe off discolouration caused by carrots, herbs or spices with a paper towel and some cooking oil. The processor may become scratched if used for processing such coarse ingredients as rock sugar, hard kinds of salt (e.g. Himalayan salt), etc. You can remove off-tastes by crushing a slice of toast. This allows you to both remove the taste and reuse the toast crumbs for other purposes. Wipe the processor out with a damp cloth. When cleaning the processor, do not immerse the processor in dishwater to prevent damage to the bearing.

**Only put into operation with the lid closed! The short operating time is 3 minutes. Do not clean in the dishwasher!**

**Please note that processors and grinders may only be operated with the ESGE-Zauberstab®.**