


说明书菲林制作单

| | |
|--------|----------------------|
| 物料编码 | 16163000A30845 |
| 型 号 | YD1634W |
| 名 称 | 说明书 |
| 印刷颜色 | 单色印刷 |
| 材 料 | 封面封底105g哑粉纸+内页80g双胶纸 |
| 尺 寸 | 145X210mm |
| 设计/日期 | 韦婷婷 20231211 |

DEVANTI®



Water Dispenser

User's Manual

Model: WD-B-BL-FS1634-BK

Please read the manual carefully before operating your water dispenser.
Retain it for future reference.

DIRECTORY

| | |
|----------------------------------|---|
| A: SAFETY PRECAUTIONS | 1 |
| B: GETTING STARTED | 2 |
| C: PART NAME | 3 |
| D: DISPENSING WATER | 5 |
| E: TROUBLESHOOTING | 6 |
| F: CLEANING | 6 |
| G: MACHINE INSTALLATION | 7 |
| H: MAINTENANEC INSTRUCTION | 8 |

The packaging material used is recyclable; we recommend that you separate plastic, paper and cardboard and give them to recycling companies. According to WEEE (Waste of Electrical and Electronic Equipment) guidelines, waste from electrical and electronic devices should be collected separately. If you need to dispose of this appliance in the future, do NOT throw it away with the rest of your domestic garbage. Instead, please take the appliance to the nearest WEEE collection point, where available.



A: SAFETY PRECAUTIONS

WARNING

To reduce risk of injury and property damage, user must read this entire guide before assembling, installing & operating dispenser.

Failure to execute the instructions in this manual can cause personal injury or property damage.

This product dispenses water at very high temperatures. Failure to use properly can cause personal injury.

When operating this dispenser, always exercise basic safety precautions, including the following:

- Prior to use, this dispenser must be properly assembled and installed in accordance with this manual.
- This dispenser is intended for water dispensing only. Do NOT use other liquids. Do NOT use for other purposes. Never use any other liquid in the dispenser other than known and microbiologically safe bottled water.
- For indoor use only. Keep water dispenser in a dry place away from direct sunlight. Do NOT use outdoors.
- Install and use only on a hard, flat and level surface.
- Do NOT place dispenser into an enclosed space or cabinet.
- Do NOT operate dispenser in the presence of explosive fumes.
- Position back of dispenser no closer than 20cm from wall and permit free airflow between wall and dispenser. There must be at least 20cm clearance on the sides of the dispenser to permit airflow.
- Use only properly grounded outlets.
- Do not use an extension cord with your water dispenser.
- Always grasp plug and pull straight out from outlet. Never unplug by pulling on power cord.
- Do NOT use dispenser if cord becomes frayed or otherwise damaged.
- To protect against electric shock, do NOT immerse cord, plug, or any other part of dispenser in water or other liquids.
- Ensure dispenser is unplugged prior to cleaning.
- Never allow children to dispense hot water without proper and direct supervision. Unplug unit to prevent unsupervised use by children.
- Service should be performed only by a certified technician.
- Warning: Do not damage the refrigerant circuit.

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- This appliance is intended to be used in household and similar applications such as: staff kitchen areas in shops, offices and other working environments; farm houses and by clients in hotels, motels and other residential type environments; bed and breakfast type environments; catering and similar non-retail applications.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- The appliance must not be cleaned by a water jet.
- The appliance is suitable for indoor use only.
- WARNING: Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- WARNING: Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- The appliance must not be immersed.
- This appliance should work under environment of temp from 10 °C ~43 °C humidity ≤90%.
- This appliance is not suitable for installation in an area where a water jet could be used.
- Never turn the machine upside down or lean it more than 45°.
- Thermostat has been adjusted. No need to adjust it by yourself. When the machine is under the ice point and blocked by ice, the cooling switch must be closed for 4 hours before turning it on again to continue its operation.
- This machine should not be turned on until 3 minutes later after turning off the power switch.
- It is recommended to use bottled pure water. If you use hard water, may lead to hot pot furring or detonation tank or pipeline risk. If you need cleaning tube, remove scale, need to find a professional instructions and professional operation.
- This product is not recommended at an altitude of 1500 meters above the region to use.
- Rated voltage :220-240V~/ 50/60Hz
- WARNING: When positioning the appliance, ensure the supply cord is not trapped or damaged.
- WARNING: Do not locate multiple portable socket-outlets or portable power supplies at the rear of the appliance.

B: GETTING STARTED


Locate Dispenser

1. Place dispenser upright.
2. locate dispenser on a hard and level surface in a cool shaded location near a grounded wall outlet.

Notice: DO NOT plug in power cord yet.

3. Position dispenser so the back is at least 20cm from wall and there are at least 20cm of clearance on both sides.

C: PART NAME



| NO. | PART NAME | NO. | PART NAME |
|-----|-----------------------------|-----|----------------------|
| 1 | top cover | 8 | water collector |
| 2 | push button of cold water | 9 | door |
| 3 | push button of normal water | 10 | heating switch |
| 4 | push button of hot water | 11 | coolingswitch |
| 5 | tap of cold water | 12 | power cord |
| 6 | tap of normal water | 13 | outlet of hot water |
| 7 | tap of hot water | 14 | outlet of cold water |

NOTE:

This machine can be suitable for bottle of 3 or 5 gallons.
Don't use unhealthy hard water.

Install water bottle

1. Open cabinet door.
2. Place probe assembly on probe hanger.
3. Place fresh bottle outside of cabinet.
4. Remove entire plastic cap from top of bottle.
5. Clean outside of new bottle with a cloth.
6. Place probe into bottle.
7. Slide collar down until it clicks in place.
8. Push head down until tube hits bottom of bottle.
9. Slide bottle into cabinet and close door.

Provide Electricity

Plug cord into a properly grounded wall outlet.



At this time the pump will begin to move water from the bottle to the hot and cold tanks. It will take up to 5 minutes to fill the tanks for the first time. During this period the pump will run continuously. This is normal.

Activate Heating & Cooling

Notice: This unit will not dispense hot or cold water until the switches are activated.

To activate, push top side of power switches in to start heating and cooling water.

- If you do not want to heat water, push bottom side of red switch in.
- If you do not want to cool water, push bottom side of green switch in.



D: DISPENSING WATER

This unit has been tested and sanitized prior to packing and shipping. During transit dust and odors can accumulate in the tank and lines. Dispense and dispose at least one quart of water prior to drinking any water.

Dispensing Cold Water

After setup, it will take up to 2.5 hour to get water to maximum cold temperature.

1. Position bottle, glass, pitcher or cooking pot below spout.
2. Depress cold water control downward to start cold water flow.
3. Release control once desired fill level is achieved.

Dispensing Normal Water

1. Position bottle, glass, pitcher or cooking pot below spout.
2. Depress normal water control downward to start normal water flow.
3. Release control once desired fill level is achieved.

Dispensing Hot Water

After setup, hot water will be available in 15-20 minutes.

1. Position bottle, glass, pitcher or cooking pot below spout.
 2. Slide red button away from you and depress hot water control downward to start hot water flow.
 3. Release control once desired fill level is achieved.
-

Changing Bottles

A flashing red light on your function lights alerts you when your bottle is empty. Replace the bottle as soon as possible.

Notice: Do not dispense hot, cool or cold water if the red light is flashing as you could empty the tanks and cause the dispenser to overheat.

1. Open dispenser door.
2. Slide empty bottle out of cabinet.
3. Remove probe assembly from empty bottle. Place probe assembly on probe hanger.
4. Set empty bottle aside.
5. Place fresh bottle outside of cabinet. Remove entire plastic cap from top of bottle. Clean outside of new bottle with a cloth.
6. Place probe into bottle. Slide collar down until it clicks in place. Push head down until tubes hit bottom of bottle.
7. Slide bottle into cabinet and close door.

E: TROUBLE SHOOTING

Water is leaking.

- Unplug dispenser, remove bottle and replace it.

No water is coming from the spout.

- Make sure the bottle is not empty. If empty, replace it.
- Make sure to completely depress the pushbutton controls.
- Remove the screws on the top cover and take off the top cover, Check whether the button push rod comes out of the faucet, and put the button push rod into the faucet

NOTE: Please scan the QR code for operation guideline in case of no water coming out from warm water tap.



Cold water is not cold.

- It takes up to 2.5 hours after setup to dispense cold water.
- Make sure the power cord is properly connected to a working outlet.
- Make sure the back of the dispenser is at least 20cm from a wall and there is free airflow on all 20cm sides of the dispenser.
- Make sure green power switch on back of dispenser is ON.
- If water still isn't cold, please ask a service agent for assistance.

Hot water is not hot.

- It takes 15-20 minutes after setup to dispense hot water.
- Make sure the power cord is properly connected to a working outlet.
- Make sure red power switch on back of dispenser is ON.

Dispenser is noisy.

- Make sure the dispenser is positioned on a level surface.

F: CLEANING

To avoid accidents, cut off the power supply before operation according to the following instructions.

1. The machine was disinfected before being shipped from the factory. Clean the dispenser prior to installing a full bottle of water for the first time.
2. **Sanitizing**

This machine should be sanitized with a disinfectant and then cleaned with water every three months. (See cleaning and draining instructions.)

3. To Remove Mineral Deposits:

Mix 4 L of water with 200 g of citric acid crystals, putting the mixture into the machine making sure the water can flow out of the hot water tap. Switch on the power and heat it for about 10 minutes. 30 minutes later, drain the liquid, then clean it with water two or three times. Never disassemble by yourself to avoid damaging machine. Generally this should be done every six months.

G: MACHINE INSTALLATION

To prevent the machine from swaying or falling, Please install the bracket accordingly.

1-2. Loosen the screw of the left or right bottom angle



Just as the picture shown

3. Use the screw to fix the bracket on the left or right bottom angle of the water dispenser.

4. Make a hole on the floor's surface where The water dispenser will be installed.

5. Fix the bracket on the floor by screwing tightly.

6. Tighten the screw.



WARNING! To avoid a hazard due to instability of the appliance, it must be fixed in accordance with the instructions.

