

KITCHEN PRO

OWNER'S MANUAL



PRIMA Plastic Pasta Drying Rack

IMPORTANT

Read and follow all warnings and instructions before assembly and use.
Keep this manual for future reference.

Specifications

- Model: 731705
- Size: 43x43x45.5cm
- Material: Polycarbonate, stainless steel

Product features

The Kitchen Pro Prima Plastic Pasta Drying Rack is designed to help dry fresh homemade pasta quickly and evenly. Hang fresh pasta strands like fettuccine, linguine or spaghetti so they dry evenly without sticking together


- Stainless steel stand with polycarbonate hanging rods
- Non-slip feet
- The rotating drying arms provide convenient access when transferring fresh pasta directly from your pasta machine

Safety information

- This product is intended for household use only.
- Keep out of reach of children when assembling or disassembling.
- Do not place near open flames or direct heat sources.
- Ensure the drying rack is fully opened and stable before use.

Get to know the Kitchen Pro Prima Stainless Steel Pasta Machine

Please ensure all components are included before assembly:




Before first use

- Remove all packaging materials.
- Wash all removable plastic components with warm soapy water.
- Dry thoroughly before assembly and use.
- Place the drying rack on a clean, dry, and stable surface.

Assembly instructions


Step 1 – Unfold the base

Gently pull down the three legs of the drying rack and spread them fully apart until the unit is stable and sits evenly on the benchtop.




Step 2 – Position the drying rack

Place the drying rack on a flat, stable, and uncluttered work surface.



Step 3 – Extend the drying arms

Turn the top handle clockwise to gradually open and extend the drying arms in a spiral formation.



Step 4 – Insert the pasta transfer wand

Insert the pasta transfer wand into the top opening of the drying rack until securely positioned.


Operating instructions

Step 1 – Prepare fresh pasta

Prepare fresh pasta using your pasta machine or homemade dough recipe.


Step 2 – Remove the transfer wand

Remove the transfer wand from the top of the drying rack before placing pasta onto the drying arms.




Step 3 – Transfer pasta onto the rack

Use the curved transfer wand to lift fresh pasta strands and gently slide them onto the drying arms.




Step 4 – Rotate the rack

Rotate the drying rack as needed to evenly distribute pasta across multiple drying arms.



Step 5 – Continue loading pasta

Repeat the process until all pasta has been placed onto the rack..



Drying tips

- Lightly dust pasta with flour before drying to prevent sticking.
- Avoid overcrowding the drying arms.
- Ensure good air circulation around the rack for faster drying.
- Drying time will vary depending on pasta thickness and room humidity.
- Fresh pasta may be cooked immediately or dried further for storage.

Cleaning and maintenance

- Clean the drying rack after each use.
- Wipe plastic parts with a soft damp cloth or wash removable components with mild soap and warm water.
- Dry all parts thoroughly before storage.
- Do not use abrasive cleaners or scouring pads.
- Store in a cool, dry place.

Storage instructions

1. Remove any remaining pasta residue.
2. Fold the drying arms inward by turning the top handle.
3. Fold the tripod legs inward for compact storage.
4. Store the unit in a dry place away from direct sunlight.

Get in touch with Customer Service

If you experience any issues with your Kitchen Pro Prima Plastic Pasta Drying Rack 43cm, get in touch with our Customer Service team by email at customerservice@kitchenwarehouse.com.au or by phone on 1800 332 934 between the hours of 9am and 7pm (AEST) Monday to Friday.

Warranty

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

The benefits of this warranty are in addition to any rights and remedies imposed by Australian State and Federal legislation that cannot be excluded. Nothing in this warranty excludes, restricts or modifies any State or Federal legislation applicable to the supply of goods which cannot be so excluded, restricted or modified.

Guarantee

We warrant that, subject to the exclusions and limitations below, the Product will be free from defects in materials and workmanship under normal domestic household use for the five year warranty period. The warranty period commences on the date of sale by the original retailer to the original purchaser. The warranty applies only while the Product is owned by the original purchaser.

Use of the Product in a commercial capacity will void this warranty. If a defect appears in the Product before the end of the warranty period and we find the Product to be defective in materials or workmanship, we will replace the Product with a product comparable in quality and value.

We reserve the right to change or discontinue our product ranges at any time without notice and without liability.

Exclusions

This warranty does not apply if proper care and/or usage instructions are not followed. This warranty does not cover scratches, stains, discoloration or damage caused by misuse.

How to claim

If a fault/defect is identified cease using the Product immediately. To make a claim on this guarantee, take the Product, proof of purchase and full details of the alleged defect to any Kitchen Warehouse store.

Limitations

We make no express warranties or representations other than as set out in this guarantee. The replacement of the Product or the refund of the purchase price is the absolute limit of our liability under this guarantee.

KITCHEN PRO

Distributed by Kitchen Warehouse.

Kitchen Pro is a registered trademark of Kitchen Warehouse Pty Ltd. The printed material appearing in this document and related packaging is protected by copyright. Illustrations in this manual are for reference only and may differ from the actual product.

Kitchen Warehouse Pty Ltd

1 Pensioner Guard Road

North Fremantle, WA, 6159

www.kitchenwarehouse.com.au

1800 332 934

customerservice@kitchenwarehouse.com.au